



Nordic Antler Iron Table Lamp

TABLE AND FLOOR LIGHTING | SKU NOT PROVIDED

MATERIAL	LIGHT SOURCE	VOLTAGE	INSTALLATION
Iron, Marble	LED / Incandescent / Fluoresc...	110V-120V / 220V-240V	See product label

SPECIFICATIONS

MATERIAL	Iron, Marble
LIGHT SOURCE	LED / Incandescent / Fluorescent
VOLTAGE	110V-120V / 220V-240V

INSTALLATION OVERVIEW

- 1 Unpack on a soft, clean surface and check all components for shipping damage.
- 2 Assemble the base, stem, shade, and lamp holder only in the sequence indicated by the supplied components.
- 3 Place the lamp on a stable, dry surface and use only the lamp type shown on the product label.
- 4 Do not use a damaged cord, plug, adapter, battery, or charger.

SAFETY

Disconnect power before electrical work. Hardwired fixtures must be installed by a qualified licensed electrician in accordance with local electrical codes. Product components and ratings can vary by option; confirm all values on the product label and supplied instructions before installation.

CARE

Switch off and allow the fixture to cool. Dust with a soft, dry cloth. Do not use abrasives, solvents, or excess moisture. Natural stone, glass, ceramic, wood, and hand-finished metal may show normal variation.